

B & K MODEL E-200D PARTS LIST

ATIC
L

DESCRIPTION	B & K PART No.
MISCELLANEOUS	
Output Transformer	061-011-9-001
Power Transformer 117V AC Primary	065-060-9-001
Power Transformer 117/234V AC Primary	065-060-9-002
Meter, 2 1/4", 200 μ A, 600 Ω	320-027-9-001
Fuse, 1/4 amp. 3AG	191-251-3-104
Case, Top & Back	272-080-9-902
Case, Sides & Bottom	272-070-9-903
Cursor Marker	380-144-9-001
Glamor Cap (Black)	384-008-9-001
Neon Lamp w/100K Resistor	401-001-9-002
Line Cord 3-wire	420-013-9-001
RF Cable Assembly	532-004-1-000
Speaker, 8 Ω , 2 1/4"	580-005-9-001
Clip Tinnerman (Speaker)	652-027-9-001
Red Jewel w/Nut	750-003-9-001
Knob, Small	751-005-9-002
Knob, Large	751-005-9-004
Knob, Cursor Drive Assembly	521-079-9-001
Dial Frequency	756-005-9-903
Dial Drive, Planetary	769-042-9-001
Extender Shaft	769-047-9-001
Coupling, 1/4" Shaft	769-057-9-001
Binding Post, Red	773-022-9-805
Binding Post, Black	773-023-9-805
Instruction Manual	480-108-9-001
Container, Shipping	500-170-9-001
Fillers, Carton	503-047-9-001
Attenuator Printed Circuit Board Complete	532-004-1-100

E: Standard value resistors and capacitors are not listed, values may be obtained from schematic diagram.

num charge \$5.00 per invoice. Orders will be shipped C.O.D. unless previous account arrangements have been made or remittance accompanies order. ace remittance must cover postage or express charge.

fy serial number when ordering replacement parts.

B & K MODEL E-200D PARTS LIST

488-101-9-002F

SCHEMATIC
SYMBOL

SCHEMATIC SYMBOL	DESCRIPTION	B & K PART No.
CONTROLS		
R-28	30K Ω , Trim Pot—Mixer Adjust	008-049-9-002
R-42, 48	1K Ω , Trimpot—Carrier Cal. & Audio Osc.	008-068-9-001
R-50	50K Ω , Trimpot—RF Threshold	008-093-9-001
R-54	10K Ω , Trimpot—Mod. Cal.	008-058-9-001
R-60	100 Ω , Fine Attenuator	008-132-9-001
R-79	10K Ω , Pot. Mod. Level	008-133-9-001
CAPACITORS		
C-41A, 41B	Dual, Var. Condenser	029-010-9-001
DIODES AND TRANSISTORS		
D-1, 2, 4, 5, 7	Diode, Silicon, 1 Amp 600 PIV	151-018-9-001
D-3	Diode, Germanium	150-003-9-001
D-6	Diode, Zener, 10V, 1 W, 5%	152-016-9-001
D-8	Diode, Germanium	150-001-9-001
Q-1	NPN, Transistor	176-040-9-001
Q-2, 5, 7, 8, 11	NPN, Transistor	176-021-9-001
Q-3	NPN, Transistor	176-022-9-001
Q-4	NPN, Transistor	176-005-9-001
Q-6, 9, 10	NPN, Transistor	176-020-9-001
SWITCHES		
S-1	Range Rotary Switch	083-097-9-001
S-2	Xtal Rotary Switch	083-103-9-001
S-3	Mod. Selector Rotary Switch	083-099-9-001
S-4	Slide Switch Meter	084-014-9-001
S-5, 6, 7, 8, 9, 10	Slide Switch (Step Attenuator)	084-029-9-001
COILS AND CHOKES		
CH-1, 2	Choke, Line Filter	041-034-9-001
L-1	Choke, 10 mh	041-001-9-023
L-2	Peaking Coil 2.5 mh	041-028-9-001
L-3	Oscillator Coil 100 KHz	044-011-9-001
L-4	Oscillator BAND "A" 100 KHz-370 KHz	044-022-9-001
L-5	Oscillator BAND "B" 370 KHz-1.4 MHz	044-022-9-002
L-6	Oscillator BAND "C" 1.4 MHz-5.1 MHz	044-022-9-003
L-7	Oscillator BAND "D" 5.1 MHz-16 MHz	044-022-9-004
L-8	Oscillator BAND "E" 16 MHz-54 MHz	044-022-9-005

COMPOSITE
499-024-9-001J